

## **Electronic BAH-1000 Thermostat** **by Big Apple Pet Supply.**

A) Place the probe in the enclosure and secure to wall with suction cup or use high quality adhesive tape on the wire near the probe but never cover the probe with anything. Choose a location that is near the heat source but not necessarily directly under the heating source. For heat mats we recommend that you place the probe directly on the mat. In general, the probe should be placed in the warmest area of the enclosure or near the basking area. The temperature reading on the thermostat indicates the temperature at the location of the probe.

B) Plug the Electronic BAH-1000 Thermostat into a 120 V 60 HZ power outlet.

Plug heat sources (ie. Incandescent lamps, heat mats, heat tape, ceramic heat emitters, etc.) into Electronic BAH-1000 Thermostat. It is important to remember that the controller will handle heating devices totaling but not exceeding 1000 watts.

Note: heat rocks are not designed to increase the temperature of enclosures so they cannot be used effectively with this type of controller.

C) Set the Electronic BAH-1000 Thermostat near the high end of the temperature range recommended for the species. This is recommended to reflect the temperature of the “warm” end of the enclosure, near the probe.

Allow Electronic BAH-1000 Thermostat to adjust enclosure temperature for 1 hour. If heat source remains on, continue to monitor until desired temperature is achieved which is indicated by the heat source turning off and on. **IMPORTANT:** if heat source remains on after 6 to 8 hours and desired temperatures are not achieved, additional or more powerful heat sources will be necessary.

**NOTE: Electronic BAH-1000 Thermostat must be placed outside the enclosure while temperature probe must be place inside the enclosure. DO NOT IMMERSE IN WATER.**

### **Important Information About Heating Reptile Enclosures:**

In most enclosures, a natural gradient occurs from one end of the enclosure to the other. Slight heat gradients are desirable, offering the reptile temperature variations found in nature.

An additional thermometer at the end of the end of the enclosure or use of a dual location digital thermometer is recommended to determine the temperature range existing between the warm and cool ends of the enclosure.

Big Apple Pet Supply warrants the Electronic BAH-1000 Thermostat to be free from defects for 180 days from purchase date. Warranty does not apply to thermostats sold outside the U.S. You must establish the purchase date with a dated sales receipt. If you believe your thermostat is not performing correctly just call us toll free at 1-800-92-APPLE or email us at [Sales@BigApplePetSupply.com](mailto:Sales@BigApplePetSupply.com) and we will instruct you with the return procedure.

If you have any questions about the Electronic BAH-1000 Thermostat please call, email or write us. We thank you for purchasing a Big Apple Product.

  
**Big Apple**  
**Pet Supply**  
415 Oser Ave, Bldg F  
Hauppauge, NY 11788  
1-800-92-APPLE  
(1-800-922-7753)  
[www.BigApplePetSupply.com](http://www.BigApplePetSupply.com)