

[Click Here to Return to the Accu-Temp 6000 at Big Apple
Pet Supply](#)

Accu-Temp 6000

Digital Thermoelectric Incubator

Thank you for purchasing the Accu-Temp 6000 TM Digital Thermoelectric Incubator.

Please read this manual carefully before use and operate according to the instructions provided..

Features

Whisper Quiet Operation with Mute Function

Digital Temperature Control

Programmable temperature range of 36 to 140 F. This provides an accurate incubating temperature for any reptile or bird species.

Large LED Digital Readout

Quick monitoring of the incubator's temperature.

Interior LED White Light

Front panel switch allows clear viewing of your reptile eggs with a bright LED light.

Front Panel On/Off Switch

Adjustable Shelf

Includes a shelf that can be adjusted to three different heights. If you need another shelf, see the last section of this manual and find out how to make your own.

Slide Out Humidity Tray

Large tray for maintaining high humidity.

Convenient Carry Handle

Car Adapter

In case of home power outages, or if you're just on the go, the Accu-Temp 6000 also comes with a 12V Car Adapter.

Operations

Follow these instructions BEFORE putting your eggs in the incubator.

1. Research the temperature required for incubation of your specific species.
2. Fill the water tray at the bottom of the unit. This tray should be filled with water throughout incubation. Make sure to check the water regularly since it will evaporate, creating humidity.
3. Set your temperature using the up and down buttons located on the front panel. The unit will automatically heat or cool based on your temperature setting. Due to the size of the incubator, there is a temperature variation of 2 degrees from top to bottom. The digital readout reflects the temperature at the top of the unit. Monitor the temperature for 24 hours to ensure its accuracy.
4. To further test the temperatures, you can place small containers of water at each level in the incubator. After 4 hours, check the water temperatures. The temperature of the incubator can be adjusted based on your readouts.

You're now ready to place your eggs into the incubator.

Technical Specifications

Power Consumption:

DC Power: Cool Mode 50W, Hot Mode 40W

Size:

Interior Dimensions: 9.5" x 10.5" x 14.5"

Exterior Dimensions: 13" x 15" x 19"

Operating Voltage:

12V DC or 110V AC, with two adapters designed for use in home or travel.

For AC (home) use: Plug one end into back of unit, other end into wall socket.

For DC (travel) use: Plug one end into back of unit, other end into car, boat, truck, van, or RV cigarette lighter socket.

Maintenance and Cleaning

- Accumulated dust will impede the air flow affecting the cooling & warming capability of the unit.
- Disconnect power before cleaning
- Use clean wet cloth & neutral detergents to clean - strong chemicals may damage plastic parts.
- Do not immerse in water
- For dirt on ventilator, use a vacuum cleaner or soft brush to remove dust, then wipe with damp cloth.

Safety Precautions

1. Keep out of reach of water or rain for proper use and to protect against electrical shock.
2. Do not pull the power cord. Make sure the plug is tightly fitted into the power socket.
3. Turn off the unit and disconnect from socket when not in use.
4. Do not touch the power plug if your hands are wet.
5. To avoid electrical shock, do not open the rear cabinet for repair or cleaning unless done by an authorized agent.
6. Place the unit on a safe, flat, stable surface when in use.
7. Keep out of reach of children.

Need an extra shelf?

1. Use foam core board, corrugated plastic, or acrylic. These can be found at most craft or hardware stores. These types of materials work well, but make sure they are sturdy enough to support your eggs.
2. Using the supplied shelf as a template, create your new shelf by tracing its outline onto your selected material.
3. Cut the new shelf out using the lines you just traced. To properly ventilate the new shelf, we suggest creating several small holes. These holes can be approximately 1/4".
4. Your new shelf can be utilized in any one of the three levels.

[Return to Accu-Temp 6000 at Big Apple Pet Supply](#)